


Fig. 14—Adjusting Lever Nose Contact at $\frac{1}{4}$ in. from Center Line.



- (1) Connect the gearshift and parking lock cables to the control unit. Secure the cable housings by clamping them in the central brackets.

Installation

(3) Loosen the lock nut and rotate the cam so the lever nose just touches the neutral slide pin as it passes over the pin when moving the parking lock lever from the **OFF** to **ON** position. Only light contact should occur so the lever does not hang up on the pin. Hold the cam in this position and tighten the lock nut to 95 inch-pounds torque. Install overcenter spring.

(4) Adjust the lever stop screw to obtain .010 inch clearance between the neutral slide pin and the lever heel (Fig. 15). Tighten the lever stop screw lock nut securely.

(2) Hold the neutral slide in against the rocker bar with about 5 to 10 pound load.

cated.

-exists in the neutriai shade, neutriai shade pin and bush-

(1) Remove the overcenter spring and back off the lever stop screw (Fig. 14). Make sure no binding exists in the outer slide bearing and bushing.

adjustment at the transmission before adjusting the

Imperial Models: Remove the better temperature control trim plate, carefully remove the plate. Depress the spring lock on the light switch and pull out the switch knob and shaft. Loosen the set screw and remove the wiper control knob. From the back remove the two nuts securing the left switch panel and name plate, carefully remove the switch panel and bezel assembly off the push buttons.

(4) Remove all the push buttons (except neutral button) by pulling them off the control actuators. (5) Using a socket and long extension through the push button opening, remove the two nuts securing the push button and pull the assembly off the clus- ter. Carefully work the assembly rearward out of the clus- ter. (6) Remove the neutral push button, and disconnect the gearshift and parking lock cables from the control unit.

(3) Chrysler Models: Remove the parking lock han-
dle from the arm (Fig. 12). Remove the retaining
screws and remove the plate beneath the instrument
cluster hood; the chrome moulding from the left side
of the instrument panel, and the push button bezel
and light seal.

- (1) Disconnect the negative (ground) cable from the battery.
- (2) Disconnect the back-up lamp switch wire connection from the switch (if so equipped).

(1) Disassemble the casting (second) shell from the casting base.

5. PUSH BUTTON CONTROL UNIT

the linkage to obtain the proper snit pattern. Refer to Paragraph 13.

(4) Adjust the transmission and carburetor throat fuel system, Group 14.

(3) Adjust the engine idle in neutral. Refer to the

(—) *Urgyansha* the *Bogd Khan* of Mongolia, who gave up his throne in 1911.

(2) Adjust the earshift control cable. Refer to Part 12.

(1) Adjust the kickdown band. Refer to Paragraph 1-26 for changing carburetors.

The following adjustments should be performed at 32,000 mile intervals or more frequent under severe operating conditions.

Periodic Adjustments

C A U T I O N: To prevent dirt from entering the transmission, make certain that the dip stick cap is fully seated onto the filter tube.